Dimensioning Rules for Braking Devices

3.11

All data sheets and commissioning instructions are available on our homepage at: www.peter-electronic.com

Configuration Instructions:

The motor ratings or nominal motor currents specified or recommended on the datasheets for the use of a braking device refer to normal applications with drives having a moment of inertia that approximately equals the moment of inertia of the motor. In all other cases, the required braking torque or braking current need to be determined more precisely (see below).

I_P

Without taking into account any possible braking torques of the load, the required braking current (direct current) can be estimated according to the following formula:

> Values usual for t_A: 1 14

$I_B = f_B \times$	$\frac{t_A}{t_B} \times I_N$
--------------------	------------------------------

- Braking current in A
- Braking factor acc. to the table specified below f_B
- \mathbf{t}_{B} Braking time required in s
- Nominal/rated motor current in A I_N
- Time until nominal speed is reached (in the case of motors with star-delta t۸ start - approx. switch-over time)

Conv Comp	eyor belt - 20 pressor - 10	os Pum _i os Fan	o - 8s - 20s	Power crusher Circular saw	- 30s - 10s
Connection of motor	winding				
at nominal operation	during	braking			
Y		$\int_{a}^{a} f_{B} = 3$			

 $f_{\rm B} = 2.6$

 \wedge

The two following examples are to explain the calculation:

Example 1

Assumption

on:	Motor shaft power:	2.2kW (230V/400V)
	Nominal motor current (2-pole motor):	8.5A/4.9A
	Ramp-up time (circular saw):	6s (direct start)
	Braking frequency:	1/h

 \wedge

The application of the circular saw requires that, after switching the saw off, the saw disk must come to a standstill within 5s. From this, there results a maximum braking time of 5s which we use in the calculation formula, too:

$$16.1A = 3 \times \sqrt{\frac{6s}{5s}} \times 4.9A$$

In the case of this application with direct start, the motor windings are in nominal operation star-connected. Braking too is effected in starconnection, which results in a braking current of approx. 16A (fB - 3), i.e, for this circular saw, a braking device with a nominal/rated current of at least 20A, such as a VB 400-25L or VB 400-25 (with a max. braking current of 25A each), has to be used.

Example 2		
Assumption:	Motor shaft power:	30kW (400V/690V)
	Nominal motor current (2-pole motor):	56A/32.5A
	Ramp-up time (circular saw):	12s (star-delta start)
	Braking frequency:	2/h

In this example, the motor is to be braked within 5s. In the first case, braking is effected with the motor windings being star-connected and, in the second case, delta-connected.

case 1 (
$$f_{B} - 1.7$$
):
 $147A = 1.7 \times \sqrt{\frac{12s}{5s}} \times 56A$
case 2 ($f_{B} - 2.6$):
 $225A = 2.6 \times \sqrt{\frac{12s}{5s}} \times 56A$

This example shows that, if braking is effected in delta-connection, a larger braking current and therefore a larger braking device is required than in cases in which braking is effected with the motor windings being star-connected.

In case 1, a braking with 200A could be used, and in case 2, a 400A device would have to be used. For case 1, it is sensible to use a braking device featuring the star-delta contactor control option (option "APC") by means of which the motor windings are automatically starconnected during the braking operation. Besides, it is thus possible to save the costs otherwise required for the star-delta contactor combination.

The device tob e recommended for case 1 would then be a braking device of the VB 400-200 APC type.

Diameter

Thickness

Starting torque:

Circular saw disk

Moment of inertia of motor:

If you have detailed data on the drive available, such as the moment of inertia of the load and of the motor as well as the starting torque, you can determine the braking current more precisely:

Starting current in star or in delta/1.72 in A $I_B = 0.31 \times k \times I_A \sqrt{\frac{n_N \times J}{t_B \times M_A}}$ Braking in star-connection k = 1 k = 1.15 Braking in delta connection t_B Braking time required (in s) n_N Nominal speed (in 1/min) L Moment of inertia of the drive (motor with load) in kgm2 M. Starting torque (in Nm) Motor shaft power: Assumption: 15kW (400V/690V) Nominal Motor current (2-pole motor): 29.5A/17A Starting current: 140A

75Nm

5mm

0.1kgm2

800mm

For the saw disk, there results the mass "m" of approx. 20kg; based on this mass, the moment of inertia oft he saw disk is 1.6 kgm2. Consequently, the following values can be used for calculating the braking current:

$$123A = 0.31 \times 1 \times 140A \sqrt{\frac{2850 \ 1/min \times (0.1 + 1.6)kgm^2}{8s \times 75Nm}}$$

Based on a guesstimate regarding the application of the braking device, we would have offered a 100A braking device for a 15kW-motor

This example shows that if large centrifugal masses are to be braked, it is quite useful to do a precise calculation. Such a large mass, in combination with a high speed, requires a larger braking current than normally needed, which is proved by the calculation. In this case too, it would be sensible to use the above mentioned brake VB 400-200 APC.

From this equation, the influence of the speed and the moment of inertia of the drive to be braked becomes obvious.

The braking current determined according to one of the above descriptions should be less than or equal to the nominal/rated current of the braking device. If in these dimensional calculations, a braking current which equals 100% oft he nominal device current is used, please make sure that in the case of devices up to 36A the max. braking time is 20s, and for devices from 40A up the max. braking time is 40s. If braking times > 20s (devices up to 36A) or > 40s (devices from 40A up) are to be expected, it must be taken into account when selecting a braking device that the permissible max. braking current is to be accordingly reduced. For more detailed information please see the device-specific commissioning instructions.

A very importand aspect in the dimensional calculation of brakes is to take into account the cyclic duration factor (c.d.f.) indicated on the data sheets. Under no circumstances the c.d.f. be exceeded (the worst case is to be taken into account !!).

How to calculate the cyclic duration factor (c.d.f.): $c.d.f = \frac{t_B}{t_Z} \times 100 \quad \begin{array}{c} t_B & \text{Braking time} \\ t_Z & \text{Cycle time (running - braking)} \end{array}$

If the required cyclic duration factor (c.d.f.) exceeds the permissible values indicated on the data sheet, the permissible maximum braking current ist o be accordingly reduced.

The data required in this connection can be found in the device-specific commissioning instructions.

If it is not possible to reduce the braking current, a braking device with a higher braking current has to be used.

Example:

If the required c.d.f. is twice as high as the value indicated on the data sheet, a braking device of twice the nominal/rated device current hast o be used.

Dimensioning of braking contactors:

The braking contactor is switched on or off via a control contact of the braking device (no-load switching). When selecting the braking contactor, it must be ensured that the contacts are able to carry the maximally occurring braking current (nominal/rated device current). Therefore, the value "conventional thermal current" (Ith) is decisive when selecting the braking contactor. If this value is not indicated, the rated operational current for AC1-operation may be used instead.

Tip: By connecting contacts in parallel it is often possible to use a lower-priced contactor of a smaller design.

3.12

Example 3

Dimensioning Rules for Braking Devices

Dimensioning of pre-fuses:

Basically, two types of fuse are available for the user:

- 1. Fusing according to allocation type "1" DIN EN 60947-4-2.
- After a short circuit, the braking device is allowed to be inoperative.
- 2. Fusing according to allocation type "2" DIN EN 60947-4-2. After a short circuit, the braking device must be suitable for further use. However, there is the danger that the contacts of the braking relay (braking contactor) weld. Therefore, if possible, these contacts are to be checked prior to reconnecting the device to the supply. If this check cannot be carried out by the user, the device has to be returned to the producer in order to have it checked.

The following dimensioning information refers to the below operating conditions:

- Use of standard asynchronous motors
- Braking time not exceeding 20s, for braking devices up to 36A
- Braking time not exceeding 40s, for braking devices from 40A up
- Braking current not exceeding 2.5x I_{NOM} of the motor
- Cyclic duration factor (c.d.f.) not exceeding the value indicated on the data sheet

Fusing according to alloction type "1":

As pre-fuses, we recommend to use line protection fuses (utilization category gL) or automatic circuit-breakers with tripping characteristic B, C, D or K.

Taking into account the maximum braking currents that occur (normally the nominal/rated device current), we recommend fuses according to table 2, column 3.

Note! Wiring cross-sectional area according to DIN VDE 0100-430, DIN EN 57100-430.

Fusing according to allocation type "2":

The power semiconductors are to be protected by fuses of the utilization category gR (semiconductors fuses, high-speed fuses). However, since these fuses do not ensure line protection, it is necessary to use additionally line protection fuses (utilize. Category gL). As for the dimensioning of the line protection fuse (gL), please refer to table 2, column 3.

To protect the semiconductors it is necessary to select gR-fuses featuring cutoff I²t-values of the ranges indicated in table 2, column 4. In this connection, the current value of the selected fuse should not be smaller than the braking current to be expected (nominal/rated device current).

<u>Notes</u>

- On the basis of the recommended *Pt-value, braking current, and possibly the c.d.f., the fuse supplier is able to select a suitable type.* Due to the great variety of producers, sizes and types, PETER electronic does not recommend any particular fuses.
- If the value oft he fuse or cutoff-Pt is selected too small, it may happen that the semiconductor fuse reacts during braking

Table 2

max. braking current / nominal/rated device current	device type	fuse value, allocation type "1"	recommended range fo cutoff-l²t-value of semiconductor pretection fuses, allocation type "2"
6A	VB6LT	6A	150 250 A ² s
25A	VB25L VB25 VB25LT	20A	500 900 A²s
30A	VB30LT	25A	600 900 A²s
36A	VB36	25A	700 1000 A ² s
40A	VB40	35A	1400 3500 A²s
60A	VB60	40A	3000 4650 A²s
100A	VB100	63A	6000 7600 A²s
200A	VB200	125A	5000076000 A²s
400A	VB400	250A	200000 305000 A²s
600A	VB600	400A	6000001050000 A²s



Dimensioning Rules for Braking Devices